

# CEE test plug with LED display



## Application

CEE test plug with display and diagnostic function. Is a practical help for electricians to check the power supply. The test plug is connected to the outlet or connector before your equipment or cable is connected. Status is shown on the LED display.

Must not be used for permanent installation.

Test parameters: - Phase sequence

- Missing phase conductor
- Missing neutral conductor
- Missing earth conductor

Protection: IP44

Program	
16 A	CEE plug with LED display 400 V, 16 A, 5P, 6h
32 A	CEE plug with LED display 400 V, 32 A, 5P, 6h
63 A	Adapter cable 63 A to 32 A



# CEE test plug with LED display

Display								
L1	✓	✓	✓	✓	L3	L3	L3	L3
L2	✓	✓	✓	✓	L2	L2	L2	L2
L3	✓	✓	✓	✓	L1	L1	L1	L1
N	✓	✓	⚠	⚠	✓	✓	⚠	⚠
PE	✓	⚠	✓	⚠	✓	⚠	✓	⚠



Simultaneous illumination of „rotating field left“ and „rotating field right“ (also in combination with any other symbol) indicates an error, which has to be checked by a qualified electrician.

Potential cause of error: missing phases, phases swapped with N or PE,...